



INSTRUCTIONS FOR USING ANTI SEIZE LEAD-FREE COPPER PASTE

Congratulations on purchasing an Akrapovic exhaust system. Please read these installation instructions carefully. If you have any trouble installing the system please contact your authorized dealer!

IMPORTANT INFORMATION

Exclusion of Certain Liability

1. The manufacturer, importer or dealer shall not be liable for any incidental damage including personal injury or any other damages caused by improper installation or operation of the Akrapovic exhaust system. When installing the Akrapovic exhaust system be careful that the exhaust system does not touch other parts sensitive to high temperature.
2. Akrapovic makes no representation or warranties with regard to damage caused by the improper installation, use and maintenance of the Akrapovic exhaust system. The warranty is limited to defects recognized by our technical department and to normal use, and excludes items subject to normal wear (gaskets and damping wool). The guarantee is void in case of accident, modification, improper or competition use.
3. Do not attempt to install the Akrapovic exhaust system on a motorcycle or car for which it was not made or tested by Akrapovic.
4. When the exhaust system gets very hot during operation, be careful not to burn yourself on the exhaust system or parts which are in direct contact with it, even when the motor is not running. Also protect other people, especially children, from the injuries mentioned above.
5. In some cases Akrapovic exhaust system kits contain chemical products (ceramic anti-seizing grease; bolt sealant). Handle with care, do not inhale or swallow. Avoid excessive contact with skin, eyes or mucous membranes. Keep out of reach of children.
6. Technical specifications of Akrapovic exhaust systems and related products subject to change without notice.

Trademarks

The Akrapovic Exhaust System Technology logo is a registered trademark of Akrapovic d.d.

Akrapovic website

Information about Akrapovic exhaust systems and related products is available on the Akrapovic website at:
<http://www.akrapovic.com/>

Copyright

No part of the Akrapovic exhaust system or its documentation may be reproduced or distributed in any form or by any means without the prior written authorization of the Akrapovic company.

© Akrapovic, d.d. All rights reserved.

Symbols

The following symbols are used throughout these installation instructions:

! CAUTION OR WARNING

 INSTALLATION TIP

! THESE INSTALLATION INSTRUCTIONS MUST BE READ CAREFULLY IN ORDER TO ENSURE PROPER INSTALLATION AND OPERATION OF THE AKRAPOVIC EXHAUST SYSTEM AND COMPONENTS.

 WE ADVISE YOU TO LEAVE INSTALLATION TO A QUALIFIED SERVICEMAN. IMPROPER INSTALLATION MAY RESULT IN A SHORTER LIFETIME OF THE EXHAUST SYSTEM AND/OR DAMAGE TO THE MOTORCYCLE OR CAR.



USE ANTI-SEIZE LEAD-FREE COPPER PASTE (black tube); Provides trouble-free and long-lasting protection against seizing, corrosion and rusting of bolts, threaded ends, nuts, joints, etc. Also protects against vibration, wear and impact. **WARNING! Avoid eye contact. Avoid excessive skin contact. Keep out of the reach of children.**

INSTRUCTIONS FOR USING ANTI SEIZE LEAD-FREE COPPER PASTE:

Anti seize lead-free copper paste provides long-lasting protection of exhaust system parts. It creates a metallic medium between metal surfaces which does not bond with either of the surfaces, so that the joints will be kept apart even after exposure to extreme pressures or temperatures. A thin coating provides trouble-free and long-lasting protection against the seizing, corrosion and rusting of bolts, threaded ends, nuts, joints, etc. Anti seize lead-free copper paste provides protection against oxidation, corrosion, vibrations, wear and impact, and simplifies the attaching and detaching of screws, bolts and nuts.

SAFETY:

- anti seize lead-free copper paste must be stored out of the reach of children
- avoid excessive contact of anti seize lead-free copper paste with skin
- must not come into contact with mucous membranes
- must not be swallowed or inhaled
- must not come into contact with the human body, especially with sensitive parts such as the face, mouth, eyes, nose, ears etc.
- in the case of damaged skin, especially on the hand used to apply the paste (open cuts, sores etc.) the anti seize lead-free copper paste must not come into contact with the skin
- may not be burned in enclosed areas
- may not be burned or disposed of outdoors
- after using anti seize lead-free copper paste, close the tube tightly and keep out of the reach of children; when empty dispose of as chemical waste
- wash hands thoroughly after using anti seize lead-free copper paste

First aid measures

- Eye contact: Immediately flush eyes with plenty of water for at least 15 minutes and get medical attention if irritation persists.
- Skin contact: Wash with soap and plenty of water. Do not use organic solvents.
- Ingestion: Do not induce vomiting. Slowly dilute with 1-2 glasses of water or milk and seek medical attention. Never give anything by mouth to an unconscious person.
- Inhalation: Remove person into fresh air.

1. PREPARATION FOR INSTALLATION OF THE AKRAPOVIC METAL CLAMPS, BOLTS AND NUTS USING ANTI SEIZE LEAD-FREE COPPER PASTE:

For easier later removal and to prevent damage of components, we recommend that you apply the copper paste included in the kit before installing the clamp, bolt or nut.

1. Apply a thin layer of copper paste to the interior side of the metal clamp and completely cover the interior surface of the metal clamp (**Figure 1, 2**). Apply a thin layer of copper paste to the threads of the bolt or to the threads of the nut (**Figure 3, 4**).




Figure 1




Figure 2




Figure 3




Figure 4